


Installation Instructions for FDA/FDF Differential Switches

Adjusting the Set Point:

(Switch is factory set at the lowest value of the adjustment range)

- Insert a 5/64" allen key into the opening for the adjustment screw on the low side port of the switch
- For adjustment, turn the screw clockwise to increase the set point or counter-clockwise to decrease until desired set point is reached
Operate the switch through its normal cycle and make any necessary adjustments to the setting

Contact	DIN HC/HN (Fig 2)
Common	Pin 1
N.Closed	Pin 2
N. Open	Pin 3



OPERATING CHARACTERISTICS

	ADJUSTMENT RANGE (PSI)	AVERAGE DIFFERENTIAL (PSI)	PROOF PRESSURE (PSI)
FDA - 1	5 - 25	3 - 8	500
FDA - 2	20 - 45	5 - 15	500
FDA - 3	35 - 75	10 - 20	500